

Bosch CDR 500 Adapter Vehicle Use Guide



Updated thru CDR Software version 19.5.2

North American vehicles that require the CDR 500 FlexRay adapter to perform a D2M (Direct-to-Module) download. The CDR 500 FlexRay adapter is **NOT** required when performing a download through the DLC/OBD port of vehicle.

Always check the Help File section of the latest CDR software for additional vehicle information and notes!

Make	Model	2014	2015	2016	2017	2018	2019	2020	2021
Audi	A4, S4, allroad				CDR 500	CDR 500	CDR 500	CDR 500	
Audi	A5, S5, RS5				CDR 500	CDR 500	CDR 500	CDR 500	
Audi	A6, S6, Avant					CDR 500	CDR 500	CDR 500	
Audi	A7, S7, RS7					CDR 500	CDR 500	CDR 500	
Audi	A8, S8					CDR 500	CDR 500	CDR 500	
Audi	eTron / eTron GT						CDR 500	CDR 500	
Audi	Q5, SQ5					CDR 500	CDR 500	CDR 500	
Audi	Q7				CDR 500	CDR 500	CDR 500	CDR 500	
Audi	Q8					CDR 500	CDR 500	CDR 500	
Bentley	Bentayga				CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
Bentley	Continental GT						CDR 500	CDR 500	CDR 500
BMW	2-Series								*CDR 500
BMW	3-Series								CDR 500
BMW	4-Series								CDR 500
BMW	5-Series				*CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
BMW	640i GT					CDR 500	CDR 500		
BMW	7-Series			CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
BMW	8-Series						CDR 500	CDR 500	CDR 500
BMW	i3	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
BMW	i8	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	
BMW	X1			CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
BMW	X2					CDR 500	CDR 500	CDR 500	CDR 500
BMW	X3					CDR 500	CDR 500	CDR 500	CDR 500
BMW	X4						CDR 500	CDR 500	CDR 500
BMW	X5						CDR 500	CDR 500	CDR 500
BMW	X6								CDR 500
BMW	X7						CDR 500	CDR 500	CDR 500
BMW	Z4						CDR 500	CDR 500	CDR 500
Lamborghini	Urus						CDR 500		
MINI	Clubman			CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
MINI	Convertible			CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
MINI	Countryman				CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
MINI	Hardtop	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500	CDR 500
Porsche	Taycan						CDR 500	CDR 500	
Rolls-Royce	Cullinan						CDR 500	CDR 500	CDR 500
Rolls-Royce	Ghost								CDR 500
Rolls-Royce	Phantom					CDR 500	CDR 500	CDR 500	CDR 500
Toyota	Supra							CDR 500	CDR 500
Volvo	S60					CDR 500	CDR 500		
Volvo	V60						CDR 500		
Volvo	XC40					CDR 500	CDR 500		

* Depending on specific BMW 2-Series or 5-Series model; check Help File for details